ULTRASONIC

Distance and Proximity Sensors



UFP / UPA Series

Content:

Technical Data	2
Technical Drawings	3
Connection & Teach in guide	4
Sound Cones	5
Order code & Accessories	6

Key-Features:

- Available measurement ranges from 200 to 6000 mm
- Ultrasonic distance sensor or 1/2 point proximity switch
- Teachable measurement range
- M12/ M18/ M30 thread housings
- Linearity up to 0.3 %
- Working temperature -20 to +70 °C
- Measurement is independent of the targets material, surface, colour or transparency
- Protection class IP65/ IP67



TECHNICAL DATA

Distance sensor		UFP-200	UFP-400	UFP-500	UFP-800	UFP-1600	UFP-2000	UFP-3500	UPA-6000
Detection range	[mm]	25200	30400	60500	100800	801600	2002000	3003500	6006000
Repeatability *			±0.2 % /	±1 mm			±0.	.2 % / ±2 mm	
Linearity error	[%]	< 0.3				< 0.5			
Resolution	[mm]		0.125	0.2	50		1.0		1.5
Response time	[ms]	40	60	100	100	140	200	400	700
Signal output		010 V				010 V / 4	.20 mA		
Teachable measurement range						Yes			
Current consumption (no load)	[mA]	< 25				< 30			
Operating voltage	[VDC]	1230				1530)		
Inverted characteristic curve		No				Yes			
Control inputs						Yes			
Safety features				Protec	ction against re	verse polarity a	nd short circuit		
Temperature range	[°C]					-20+70			
Connection		M12 connector			M12 connec	tor, cable outpu	t		M12 connector
Design		M12x1, 79 mm		N	И18х1, 100 mm	า		M30x1.5, 125 mm	Disk, 80x80x50 mm
Case material		steel				Plastic	5		
Protection class		IP65	IP65	IP67	IP67	IP65	IP67	IP67	IP65
Angle of the sound cone						8°			

Proximity switch		UFP-200	UFP-400	UFP-500	UFP-800	UFP-1600	UFP-2000	UFP-3500	UPA-6000
Switching points		1				2			
Detecting range	[mm]	25200	30400	60500	100800	801600	202000	3503500	6006000
Repeatability *		±0.3 %	±0.5 %	±0.2 %	/ ±1 mm		±0.	.2 % / ±2 mm	
Resolution	[mm]	0.250	0.125	0.250			1.0		
Hysteresis	[%]	2				1			
Sampling frequency	[Hz]	25	15	10	10	6	5	2,5	1
Signal					ı	PNP / NPN			
Visualization of current state					LED	green / yellow			
Adjustment of switching points					by T	each-in mode			
Max. output current	[mA]	100				500			
Current consumption (no load)	[mA]	< 25				< 60			
Operating voltage	[VDC]	1030				1230)		
Switching mode						NO / NC			
Control inputs						Yes			
Safety features				Prote	ection against re	verse polarity ar	nd short circuit		
Temperature range	[°C]					-20+70			
Connection		M12 connector			M12 connec	tor, cable outpu	t		M12 connector
Design		M12x1, 79 mm			M18x1, 100 mn	ı		M30x1,5, 125 mm	Disk, 80x80x50 mm
Case material		steel				Plastic	S		
System of protection		IP65	IP65	IP67	IP67	IP65	IP67	IP67	IP65
Angle of the sound cone						8°			


 $[\]ensuremath{^{*}}$ in case two values are indicated, please choose the worse value

!! WARNING - SAFETY INFORMATION !!


These devices are not designed for critical safety or emergency shut-down purposes. Therefore they should never be used in an application, where a malfunction of the device could cause personal injury.



TECHNICAL DRAWINGS UFP SERIES




TECHNICAL DRAWINGS UPA SERIES






ELECTRICAL CONNECTIONS







TEACH-IN GUIDE

Analog Output 0...10 V / 4...20 mA (Teach-In)

Normal operation:


EC (Echo LED) GREEN: Activates whenever echo is received (support for orientation).

P1 LED, P2 LED YELLOW: One of the lamps is lit whenever the target quits the zone between P1 and P2 Teach-In (Line): Connect activating line to GND (time required for teach-in: ca. 30 sec).

Characteristic curve (P1 < P2): P1 - 0 V / 4 mA und P2 = 10 V / 20 mA

- 1. Teach-In must remain coupled to GND (ca. 6 8 sec.), until EC (Echo LED) and P1 start to flash (2 Hz) (UFP-200 only YELLOW).
- 2. Now P1 starts to flash (1 Hz), and EC (Echo) is ready to operate, serving as an aid for orientation. For UFP-200 model however, only YELLOW flashes (frequency ½ Hz).
 - The reference object has to be positioned in position 0 V/ 4 mA. Acknowledge by interconnecting Teach-In and GND, just for a 4 mamment. From now on, the sensor works in normal operation with this selected P1 value.
- 3. Connect Teach-In to GND one more time (for ca. 15 16 sec.), until EC (Echo LED) and P2 start to flash (2 Hz). For model UFP-200, only YELLOW, frequency 1 Hz).
- 4. Procedure of step 2 is repeated for P2: As soon as the reference object has been installed in position 10 V / 20 mA (do not forget to confirm, as described above), the sensor accepts the new value for P2 and uses it for further operation.

Inverted characteristic curve (P2 < P1): P2 = 0 V / 4 mA und P1 = 10 V / 20 mA





TEACH-IN GUIDE

2 point proximity switch (Teach-In)

Normal operation:

EC (Echo LED) GREEN: Is lit whenever echo is received (simplifies orientation).

P1 and P2 LED YELLOW: State of break-over point SP1 resp. SP2

Teach-In: Activating line (time required for teach-in: ca. 30 sec)

Set-up procedure for switching point SP1

- 1. Teach-In line must be coupled to GND (ca. 6 8 sec.), until EC (Echo LED) and P1 start to flash (2 Hz). For UFP-200: Only YELLOW.
- 2. P1 starts to flash at a frequency of 1 Hz, and EC LED is active (for orientation purpose). For UFP-200 however, YELLOW flashes (only ½ Hz). The reference object has to be positioned. Acknowledge by shortly interconnecting Teach-In and GND.
- 3. During teach-in, LED P1 visualizes the behavior of switching point SP1. If the lamp is lit: NO for SP1. Lamp off: NC characteristics.

Set-up procedure for switching point SP2


- 1. Teach-In line must be coupled to GND (ca. 14 18 sec.), until EC (Echo LED) and P2 start to flash (2 Hz). For UFP-200 only yellow (1 Hz).
- 2. P2 starts to flash at a frequency of 1 Hz, and EC LED is active (support for orientation). For UFP-200 however, only YELLOW flashes (½ Hz). The reference object has to be positioned. Acknowledge by shortly interconnecting Teach-In and GND). For UFP-200, the hysteresis distance should not be confirmed, before the yellow LED is illuminated.
- 3. During teach-in, LED P1 visualizes the behavior of switching point SP2. If the lamp is lit: NO for SP1. Lamp off: NC characteristics.

Window function / hysteresis function

- 1. If for UFP-200, teach-in procedure is carried out only for SP1, SP2 automatically is accepted for this distance + 1%.
- 2. If both P1 and P2 LED's are OFF, the sensor reads the window function. If an object is between P1 and P2, then: SP1 ON, SP2 OFF
- 3. If during Teach-In, both P1 and P2 LED's are lit, the sensor uses the hysteresis function. SP1 (normally open contact) and SP2 (normally closed contact) are at P1 and have the hysteresis of P1-P2.

SOUND CONE GEOMETRY


The exact geometry of the sound cone depends on the: air-pressure, temperature, humidity and size of the target.




Sound cone geometry of the models UFP3500 and UPA600 on request.



ORDER CODE UFP SERIES



ORDER CODE UPA SERIES



ACCESSORIES

Cable with M12 connector, 5-pole			
K5P2M-S-M12	2m, M12-connector straight		
K5P5M-S-M12	5m, M12-connector straight		
K5P10M-S-M12	10m, M12-connector straight		
K5P2M-SW-M12	2m, M12-connector angular		
K5P5M-SW-M12	5m, M12-connector angular		
K5P10M-SW-M12	10m. M12-connector angular		

Connector M12	?, 5-pole	
D5-G-M12-S	M12, straight	
D5-W-M12-S	M12, angular	

Cable with M12 connector, 4-pole (for UFP-200)			
K4P2M-S-M12	2m, M12-connector straight		
K4P5M-S-M12	5m, M12-connector straight		
K4P10M-S-M12	10m, M12-connector straight		
K4P2M-SW-M12	2m, M12-connector angular		
K4P5M-SW-M12	5m, M12-connector angular		
K4P10M-SW-M12	10m, M12-connector angular		

Connector M12, 4-pole (for UFP-200)				
D4-G-M12-S	M12, straight			
D4-W-M12-S	M12, angular			





Subject to change without prior notice.

WayCon Positionsmesstechnik GmbH

E-Mail: info@waycon.de Internet: www.waycon.de



Head OfficeMehlbeerenstr. 4
82024 Taufkirchen
Germany

Tel. +49 (0)89 67 97 13-0 Fax +49 (0)89 67 97 13-250 Office Köln

Auf der Pehle 1 50321 Brühl Germany

Tel. +49 (0)2232 56 79 44 Fax +49 (0)2232 56 79 45